

ECOSHOT

Manual dosing system

- Simple operation: twist and push.
- Dosing ring: To set a dose on ECOSHOT, simply turn the green ring to the matching dosage indicator. This system offers you an infinity of dosing shots between 5ml and 30ml to suit your chemical requirements.
- Built-in, flexible delay function: the unit will not function again until the green indicator has fully returned, avoiding harmful and costly misdosing.



Suitability	Concentrated chemicals (bottle/ bucket max. 150cP, sink 300cP)
Installation	Bottle height 144mm – 288mm
Operation features	Manual dose of a concentrated chemical in to a sink, a spray bottle or a bucket. Twist initiation (patented). Adjustable dose between 5ml and 30ml (patented)
Capacity	Suction from any sized container. Hanging bracket available: 5-10L. Cabinet available
Dilution rate/Dosage	Choice between 5ml and 30ml, adjustable dose
Colour options	Cover ring: grey as standard available in blue, green, red, black, yellow
Dimensions Weight	H 220 x W 120 x D 100 (max. depth 150 button)
Branding option	0.51kg YES



Twist and push operation



Green dosing ring, dosing marks



Delay mechanism